

5-Phase stepper motor driver

Wiring cable set with connector for MD-255C / MD-255E

CL-2

- This product is use for MD-255C / MD-255E only. Do not use other product.
- Please, refer the operation manual of each driver when you using this item.

● Wiring Diagram

