

# 5-Phase stepper motor driver

## Wiring cable set with connector for MD-55C / MD-55E

# CL-B

- This product is use for MD-55C / MD-55E only. Do not use other product.
- Please, refer the operation manual of each driver when you using this item.

### ● Wiring Diagram

